

POLYCORP

HEAD CLEANING

With time, the heads of the floppy disk units may become dirty. If the system will not boot up or if it is not possible to access files on Drive 1, follow the instructions below in conjunction with the instructions given in the head cleaning kit.

TO CLEAN HEADS ON DRIVE 0

Insert cleaning disk on Drive 0. Close door. Turn power on and the heads should load automatically. Clean for about 30 seconds and turn power off. Remove cleaning disk and attempt to boot system using a normal disk.

TO CLEAN HEADS ON DRIVE 1

Assuming you have loaded the system from Drive 0, insert the cleaning disk in Drive 1 and close the door.

From BASIC, type +DIR 1 several times until the heads on Drive 1 have been loaded for a total of about 30 seconds. Ignore Error messages.

Remove cleaning disk and try to get a directory of a normal disk in Drive 1.